

Create the basic robot control program. Then, upload the program to the microcontroller.

The robot servomotor program will:

- Set the pins connected to the servomotors.
- Move the robot forwards for 2 seconds.
- Stop the robot.

Use your algorithm to help create the program.

