

จากโค้ดด้านล่างนี้ จงต่อวงจรให้ถูกต้อง

```
1  #include <Wire.h>
2  #include <Adafruit_GFX.h>
3  #include <Adafruit_SSD1306.h>
4  Adafruit_SSD1306 display(128, 32, &Wire, -1);
5  const int trigPin = D3;
6  const int echoPin = D4;
7  long duration;
8  int distance;
9  const int Buzzer = D5;
10
11 void setup() {
12     display.begin(SSD1306_SWITCHCAPVCC, 0x3C);
13     pinMode(trigPin, OUTPUT);
14     pinMode(echoPin, INPUT);
15     pinMode(Buzzer, OUTPUT);
16 }
```

