


Rice Cooker



[] Scoop

[] Measuring Cup

[] Lid

[] Light Indicating
"WARM"

[] Light Indicating
"COOK"

[] Pan

[] Lid Knob

[] Body

[] Switch

[] Steaming Basket

[] Power Cord

[] Handle

