



Glass Print Surface

Apply blue tape or glue stick and print on it!

Print Head

Sometimes referred to as the hotend. It is the part that melts the PLA.

SD Card Slot

This is where you put the SD card.

LCD Screen

Displays the menu.

X Motor

Motor that moves the X-axis.

Print Surface Clips

Holds the print surface in place while printing.

LCD Knob

Use this to navigate the menu.

Thumb Screw

Used to adjust the level of your print surface.

X Loop Belt

Connects X-motor to the gantry.

Z-Axis Endstop

This tells the print bed that it is at the home position for the Z-axis.