
Select the correct solution.



1. Monitor is not displaying anything
   a. Check if all the wires are connected correctly.
   b. Install the correct software.



2. Keyboard or mouse is not working
   a. Check if all the wires are connected correctly.
   b. Install the correct software.

LIVEWORKSHEETS