

Power

calculate the Power for the
AAA battery.




Select the answer :

Power = Voltage x Current Power
=

1.6 W

1.8 W

2 W

Battery type	Battery image	Voltage in volts (V)	Current capacity Amps (A)
Coin cell		3	0.25
AAA		1.5	1.2
AA		1.5	2.4
C		1.5	8