

- A. Punch holder of dieset
- B. Piercing Punch
- C. Pilot nut
- D. Square head set screw
- E. Jam nut
- F. Blanking Punch
- G. Punch plate
- H. Pilot
- I. Stripper plate
- J. Automatic stop
- K. Finger stop
- L. Back gauge
- M. Front spacer
- N. Die block
- O. Die holder of die set

