


Match the parts of the electrical appliances.

RICE COOKER

Lid
Pot
Rice spatula
Power switch
Steam rack
Power light
Cook light
POWER CORD
Heating plate
Knob
Measuring cup
Outer sport
Warm light
Handle



PARTS NAME



INSTALLATION



BLENDER

Food insertic Cover
Mug
Function buttons
Safety lock
Top cover
Safety lock
Main motor machine