HOW TO CLEAN A PRINTER

To ensure optimal performance, it is important to meticulously clean your printer every few months. First, make sure to disconnect the power cable to avoid any accidents. Then, use a soft, lint-free cloth to gently wipe the exterior of the printer. After that, disassemble the paper tray and remove any accumulated dust or debris. Be careful not to touch the internal components unless necessary. If the print heads appear clogged, use a designated cleaning solution to carefully clean them, ensuring no residue is left behind. Once finished, reassemble all parts and plug the printer back in. Finally, perform a test print to confirm that the cleaning was effective.