


USB

Microphone

Buttons

Touch logo

LED



Processor

Reset button

Battery socket

Speaker

Radio antenna

Compass

Pins

