

Check roof load capacity

Read the installation manual

Tighten and check structure stability

Check delivery contents

Stage 2. Installation of the Support Structure

Install mounting rails

Fix roof hooks or brackets

Level the structure

Set mounting area

Prepare tools and safety equipment

Stage 1. System Preparation

Set tilt angle

Seal mounting points

Choose mounting parts

Check installation location

1.

2.

3.

4.

5.

6.

7.

8.

9.

10.

11.

12.

13.

14.

15.